



FOR USE WITH SINGLE MODE FIBER AND 900 µm TUBING ONLY
INCLUDED BUT NOT SHOWN

- PROTECTIVE DUST CAP
- PINK EPOXY GUIDE SLEEVE
 - INSERT THE FLAT END OF THE GUIDE SLEEVE INTO THE BACK OF THE CONNECTOR UNTIL IT BOTTOMS OUT AGAINST THE FERRULE
 - USING A SYRINGE, INJECT EPOXY UNTIL A BEAD OF EPOXY PROTRUDES THROUGH THE FERRULE TIP
 - REMOVE EPOXY GUIDE SLEEVE BEFORE INSERTING THE FIBER

FOR INFORMATION ONLY
NOT FOR MANUFACTURING PURPOSES

DRAWING PROJECTION



	NAME	DATE
DRAWN	CB	13 SEP 11
APPROVAL	KAH	05 DEC 11

COPYRIGHT © 2011 BY THORLABS

VALUES IN PARENTHESIS ARE CALCULATED AND MAY CONTAIN ROUND OFF ERRORS

THORLABS
www.thorlabs.com

FC/APC Connector, 126µm, 900µm Boot		REV B
MATERIAL		N/A
ITEM #	30126K1	APPROX WEIGHT
		0.0064kg